

BANDO



Green Seal Belt

HONDA

Air Blade
SH / @ / Dylan
Spacy 100
Spacy 125 / @ Stream / E Sky
SCR/Lead
PCX/AB125/Lead125
Vision

YAMAHA

Cygnus (Taiwan Dylan)
Majesty / @ China
Nouvo
Nouvo LX135

SUZUKI

AMITY
Epicuro Avenus
Hayate
Sapphire

SYM

Attila
Excel
PIAGGIO
LX125

BANDO



Red Seal Belt

HONDA

Airblade

YAMAHA

Nouvo / MIO 110

SYM

Attila

Racing Belt

HONDA

Airblade 125 / Click

SH

PCX

YAMAHA

Nouvo / MIO 110



BANDO

Quick Line CVT Belt

For A Normal
Engine



Racing Line CVT Belt



For A Customized
Engine

BANDO

Weight Roller

HONDA

AirBlade, Click
SCR110
Spacy 100
E-Tsai, @stream
SH, @, Dylan
Spacy125
PCX125

YAMAHA

Nouvo, Mio
NouvoLX135
Cygnus125
Majesty

SUZUKI

Hayate
Amity
Sapphire
Avenus

SYM

Attila
Excel
Joyride 110



BANDO

Mạng Lưới BANDO Toàn Cầu



*Japan: BANDO CHEMICAL INDUSTRIES, LTD.
Website: <http://www.bando.co.jp/> Tel: 81-70-204-2023
Email: info@bando.co.jp

*Viet Nam: BANDO MANUFACTURING (VIETNAM) CO., LTD.
Website: <http://bando-banque.vn/> Tel: 84-83838-3038
Email: sales@bando-banque.vn

*Singapore: BANDO (SINGAPORE) PTE. LTD.
Website: <http://www.bando.com.sg/> Tel: 65-6475-2233
Email: bando@bando.com.sg

*Thailand: BANDO MANUFACTURING (THAILAND) LTD.
Website: <http://www.bandothai.co.th/> Tel: 66 81 830 6861

*Korea: BANDO KOREA CO., LTD.
Website: <http://www.bandokorea.co.kr/> Tel: 82-50-371-8200
Email: kjko@bandokorea.co.kr

*China: BANDO (SHANGHAI) MANAGEMENT CO., LTD.
Website: <http://www.bando.cn/> Tel: 86-21-5046-0161

*Taiwan: SANWU BANDO INC.
Website: <http://www.bando.com.tw/> Tel: 886-2-2567-8255

*Philippine: PHILIPPINE BELT MANUFACTURING CORP.
Tel: 63-2-241-0794

*Malaysia: KEE FATT INDUSTRIES, SDN.BHD.
Tel: 60-7-463-1877

*Indonesia: P.T. BANDO INDONESIA
Website: <http://www.bandoindonesia.com/> Tel: 62-21-3902020

*India: BANDO (INDIA) PVT. LTD.
Tel: 91-124-6305600

BANDO

HONDA YAMAHA SUZUKI SYM



BANDO

Các Dấu Hiệu Dây Curoa Cần Thay Thế

- +Xe đã chạy được trên 15,000 km.
- +Hoạt động của xe bắt đầu đi khập khiễng khi đi chuyển, cảm thấy nặng nề, không linh hoạt.
- +Tiếng máy xe không còn êm ái. Trong lúc nổi phát ra âm thanh lạ lạch phạch, hoặc tiếng cọt rít.
- +Tổn nhiên liệu hơn bình thường.
- +Xe hoạt động không ổn định.

1st: Kiểm tra phần bụng của dây



2nd: Kiểm tra các vết nứt 2 bên hông của dây



3rd: Kiểm tra các vết nứt trên bề mặt dây



BANDO

Dây Curoa Xe Tay Ga



2014 JUL.
BMVN 0007